



| EV # | Description | Ref Part # | Quantity |
|------|--------------------------------|--------------|----------|
| - | Gear Housing Complete (1 - 27) | WD 0019 | 1 |
| 1 | Adapter | 3161 0893 00 | 1 |
| 2 | Seal Ring | 3161 0852 00 | 1 |
| 3 | Screw | 0211 1367 00 | 6 |
| 4 | Clamp Ring | 3161 0619 00 | 1 |
| 5 | Seal Ring | 3161 0753 00 | 2 |
| 6 | Gasket | 3161 0622 00 | 1 |
| 7 | Gasket | 3161 0621 00 | 1 |
| 8 | Ball Bearing | 0504 0602 00 | 2 |
| 9 | Gear Housing | 3161 0626 00 | 1 |
| 10 | Grease Nipple | 0544 2162 00 | 1 |
| 11 | Spacer Sleeve | 3161 0627 00 | 1 |
| 12 | Ball Bearing | 0502 2112 00 | 1 |
| 13 | Spacer Ring | 3161 0630 00 | 1 |
| 14 | O Ring | 0663 9194 00 | 1 |
| 15 | Spring Complete | 3161 0628 80 | 1 |
| 16 | Spindle | WD 0020 | 1 |
| 17 | Bushing | 3161 0755 00 | 1 |
| 18 | O Ring | 0663 3131 00 | 2 |
| 19 | Seal Ring | 3161 0634 00 | 1 |
| 20 | Spring | 3161 0635 00 | 1 |
| 21 | Parallel Pin | 0102 0410 00 | 2 |
| 22 | Cover | 3161 0631 00 | 1 |
| - | Insert | WD 0021 | 6 |
| 23 | Screw | 0147 1407 00 | 8 |
| 24 | Plug | 0686 6103 00 | 1 |
| 27 | Air Inlet Tube | 3161 0636 00 | 1 |

* Suffix "M" with the Ref. Part # is Modified